SAMSUNG
Galaxy Note10 | 10+

Quick Reference Guide

Unlocked[1]

Printed in Korea
GH68-50894A

Samsung Care

Samsung Premium Care

Pick the time and place and a team member will meet you to set up, troubleshoot, repair, or replace your product. Enroll at **samsung.com/us/support/premium-care**

Learn more

- Use Tips and help to access the user manual on how to use your phone. To open, from **Settings** tap **Tips and help**.

Get to know your product:

- Access solutions, videos, tips, and more at **samsung.com/us/support**
- Find support that's convenient on your device with the Samsung Members app. Download and install it from Google Play™ store.

Contact us:

- Ask questions and share solutions with other Samsung customers at **us.community.samsung.com**
- Get support at **samsung.com/us/support/contact** or call us at 1.800.SAMSUNG
- Find a service location near you at **samsung.com/us/support/service/locations**

About your phone

- Power on: Long press
- Short press: Lock screen
- Long press: Bixby Voice
- Double press: Launch camera
- Power off: Long press with Volume down

Images shown are of the Galaxy Note10+ and are for reference only.

Set up your phone

Your SIM card may be pre-installed.



SIM/microSD™ tray

Use the tool to open the SIM/microSD card tray.

Place the SIM card and if applicable the optional microSD card into the tray with the gold contacts facing down.

Charge your device

Before turning on your phone, charge it fully.

Note: Use only Samsung-approved charging devices and accessories. Samsung accessories are designed for your device to maximize battery life. Using other accessories may void your warranty and may cause damage.

Backup and restore

Get help transferring contacts, photos and other content from your old phone at **samsung.com/smartswitch**

Get creative with the S Pen

Unleash the S Pen

Push the S Pen inward and, then pull it out.

When you remove the S Pen, Air command launches.

S Pen button

Press and hold the S Pen button to open an app remotely.

A single press, double press, or a gesture can capture a photo, navigate, scroll and more.

To enable S Pen Air actions, remove the S Pen and tap **Settings** > **Air actions**.

There's no limit to the S Pen

Write and draw directly into emails or the calendar, as well as Word, Excel®, PowerPoint®, and PDF documents.

Air Command

Air Command gives you access to signature S Pen features.

Create note: Create customized notes.

View all notes: View all notes created.

Smart select: Outline and crop anything on the screen and freely edit or share.

Screen write: Capture a screen image and write or draw on it.

Live message: Create live messages and GIFs.

Translate: Hover the S Pen over a word to view its definition and pronunciation.

PENUP: Use the S Pen to draw, color, edit, and share live drawings.

Add shortcuts: Select an app or function to add to the Air Command menu.



Camera

Bixby Vision
Identify objects and locations

Tools Panel
Tap to select settings or options.

AR Emoji
Turn your selfie into an emoji

Scene optimizer
Recognize subjects in photos and automatically enhance the quality

Standard (leaf), Wide (tree), and Ultra wide (forest)
Get more of the scene, by tapping the leaf, tree or forest icon

Camera modes
Swipe left or right to select a mode

Gallery
View photos

Capture
Take photo

Toggle camera
Switch between the back and front cameras



[1]Wireless voice, data and messaging services compatible with most major U.S. GSM and CDMA networks. Visit www.samsung.com for more information on your device. Support for certain features and services such as VoWiFi and hotspot, vary by wireless service provider. See provider for compatibility details.

©2019 Samsung Electronics America, Inc. Samsung and Galaxy Note are both trademarks of Samsung Electronics Co., Ltd. Other company and product names mentioned herein may be trademarks of their respective owners. Screen images simulated. Appearance of phone may vary.